

B R O M I N E

Congratulations and welcome to the exciting world of hot tubbing. Along with the delivery of your Arctic Spa you have received this Bromine Starter Kit. This kit contains products you will need to help maintain your water balance. Based on your source water quality chemicals not included in this kit may be required.

It is important to note that the below recommendations are strictly a guideline. Individual maintenance will vary based on factors such as water source, usage, body composition, bather load etc.

Starter Kit Contents	Its Job	Cap Quantity
<i>Bromine Tabs</i>	Sanitizer	
<i>Peak Boost</i>	Increase Bromine	1 cap = 25 grams
<i>Shock/Oxidizer*</i>	Oxidizer	1 cap = 25 grams
<i>Adjust Down</i>	Lowers pH	1 cap = 30 grams
<i>Adjust Up</i>	Raises pH	1 cap = 30 grams
<i>Perfect Balance</i>	Raises Alkalinity	1 cap = 25 grams
<i>Ultra Spa</i>	Conditioner	1 cap = 30 grams
<i>Best Defence</i>	Protects Equipment	see bottle
<i>Aquacheck Red Test Strips</i>	Measures Bromine	
<i>Zorbie</i>	Removes oils	
<i>Floating Dispenser</i>	Holds pucks	

Recommended Levels	
<i>Bromine</i>	4-6 ppm
<i>pH</i>	7.2-7.6
<i>Alkalinity</i>	80-120 ppm
<i>Calcium</i>	125-200 ppm

Start-up

Once the spa has been filled with water, powered up and filtration set, place the insulated cover on the spa. After the tub has reached 85°F or higher, you can begin adding the chemicals listed below. While waiting to heat up refer to your owners manual (pg 136) on how to set up home connect and your myarcticspa.com account if you have not done so already.

- 1.) Add the initial dose of **ULTRA SPA** (200 gm/1000L). Turn pump(s) on wait 1 hour
- 2.) Add the initial dose of **BEST DEFENCE** (2 oz/1000L). Turn pump(s) on wait 1 hour
- 3.) Test Alkalinity, adjust if needed to maintain 80-120 ppm
- 4.) Test pH, adjust if needed to maintain level between 7.2-7.6 (If high add ADJUST DOWN, if low add ADJUST UP)
- 5.) With pump(s) operating add 20g/1000L of **PEAK BOOST** to bather free water
Test water for bromine level and repeat dosage until 4-6 ppm is reached.
- 6.) Fill floating dispenser with **BROMINE TABS** and set to desired level

Daily or after each use

- 1.) Test and balance the water accordingly (testing before use is recommended)
- 2.) Add 25g/1500L of **SHOCK/OXIDIZER**. Wait 1 Hour before entering the spa

Weekly

- 1.) Add 60g/1000L of **ULTRA SPA**. Wait 1 hour.
- 2.) Test and balance water accordingly.
- 3.) Add 1oz/1000L of **BEST DEFENCE**.
- 4.) Add **BROMINE TABLETS** to the floating dispenser and adjust setting if necessary.
- 5.) Add 100g/1500L of **SHOCK/OXIDIZER** or if bromine levels are low add 30g/1000L of **PEAK BOOST****
****if using PEAK BOOST do not enter spa until chlorine levels return to below 5ppm**

*** PLEASE NOTE - Due to current supply issues the item referred to as shock/oxidizer may vary in both name and functionality. Please contact your sales representative should you need clarification or further instruction.**