

# LLP (Low Level Programming)



*To access Low Level Programming Press and Hold the YESS/Settings button until LLP displays then release*

*Press YESS/Setting button to scroll through the categories and the arrows up and down buttons to change.*

<b>Pumps</b>	PN 1	1 pump installed
	PN 2	2 pumps installed
	PN 3	3 pumps installed
<b>YESS</b>	Ys 0	YESS not installed
	Ys 1	YESS installed
<b>SDS</b>	SDS 0	SDS not installed
	SDS 1	SDS Installed
<b>OZONE</b>	O3 0	OZONE not installed
	O3 1	OZONE installed
<b>ONZEN</b>	On 0	ONZEN not installed
	On 1	ONZEN installed
<b>FILTER SUSPEND</b>	Fs 0	Filtration will not suspend if temp over set point
	Fs 1	Filtration will suspend if temp more then 2 F above set point
<b>BREAKER SETTING</b>	bs 16	pump 1 low speed and heater, pump 1 high no heater
	bs 20	pump 1 low speed and heater, pump 1 high no heater
	bs 25	
	bs 32	
	bs 40	1 pump high speed and heater, second pump will turn off heater
	bs 50	2 pumps high speed and heater, third pump will turn off heater
	bs 60	3 pups high speed and heater, fourth pump will turn off heater
<b>FOGGER</b>	FG 0	FOGGER not installed
	FG 1	FOGGER installed